

CR1400

QUICK START GUIDE



code

ADVANCED BARCODE READERS



www.codecorp.com



User Manual
Manuel d'Utilisateur
Manual de Usuário
Manual do Usuário
Benutzerhandbuch
ユーザーマニュアル
用户手册
사용자 매뉴얼




Configuration Guide
Guide de Configuration
Guía de Configuración
Guia de Configuração
Programmierhandbuch
設定コード表
配置指南
설정 가이드




[YouTube.com/codecorporation](https://www.youtube.com/codecorporation)

Included if Ordered


Inclus si commendé Incluido si así lo ordena Incluídos se ordenou
Inbegriffen, wenn bestellt 注文時に追加 包括若订购 주문시 포함






USB Cable
Câble d'USB
Cable USB
Cabo USB
USB-Kabel
USB ケーブル
USB 线缆
USB 케이블



RS232 Cable
Câble de RS232
Cable rs232
Cabo RS232
RS232-Kabel
RS232 ケーブル
RS232 线缆
RS232 케이블




Power Supply
Alimentation électrique
Fuente de alimentación
Fonte de alimentação
Netzteil
ACアダプタ
充电电源
Power Supply




Set Up

Installation Instalación Instalação
Einrichten 設定 设置 셋업



Scanning

Lecture Escaneo Leitura Scannen
스캔 扫描中 스캐닝



Power On

Allumer Encender Ligar Einschalten
電源オン 电源开启 Power on

