

User Manual
Manual do Utilisateur
Manual de Usuario
Benutzerhandbuch
Manual de Usuario
Manual de Usuario

Configuration Guide
Guide de Configuration
Guia de Configuración
Programmiervorbuch
Guia de Configuración
設定ガイド
設置指南
설치 가이드

www.codecorp.com



YouTube.com/codecorporation


code®
REVOLUTIONIZING BARCODE READING

QUICK START GUIDE

CR1500





code®
REVOLUTIONIZING BARCODE READING




- Power Supply
- ACアダプタ
- Netzteil
- Fonte de alimentação
- Fuente de alimentación
- Alimentation électrique
- Power Supply
- RS232 케이블
- RS232 线缆
- RS232 ケーブル
- RS232-Kabel
- Cabo RS232
- Cable rs232
- Cable de RS232
- RS232 Cable
- USB 케이블
- USB 线缆
- USB ケーブル
- USB-Kabel
- Cabo USB
- Cable USB
- Cable d'USB
- USB Cable

Included if Ordered
Inclus si commande
Incluido si así lo ordena
Incluidos se ordena
包括若订购
주문시 포함
Inbegriffen, wenn bestellt
注文時に追加




Scanning
 Lecture Escaneo Leitura Scannen
 स्कैन 扫描中 스캐닝

- 5. [Barcode icon]
- 2x [Speaker icon]
- 4. [Speaker icon]
- 3. [Sun icon]
- 2 Sec. [Lightbulb icon]
- 2. [Lightbulb icon]



Power On
 Allumer Encender Ligar Einschalten
 電源オン 電源开启 Power on



Set Up
 Installation Instalación Instalação
 Einrichten 設定 設置 设置