

Code Reader 2.0 Battery Charger



CR2 Battery Charger

The Code Reader 2 (CR2) charger features two charging bays that can accommodate either CR2 units or individual batteries. A power supply and four (4) plastic inserts are included with your charger. The plastic inserts are only used when charging a battery without the CR2 unit. Plug the power cord into the back of the unit and plug the adapter into a wall socket. The unit features two (2) LED's for displaying the charge status. The LED's will remain red until the unit is fully charged. Once charged, the LED's will turn green. The approximate charge time is 4 hours.

Installing and Removing Plastic Inserts for Charging a Battery

The charger comes with four (4) plastic inserts that must be installed if you are charging a battery only.

Follow the steps below to install or remove the inserts:



The battery charger includes four (4) plastic inserts.



To install, you must slide the inserts into the grooves inside the charging bay with the round end towards the front. Push them down hard. You will hear the inserts click into place.



To remove the inserts, grab the round part and slide it out of the grooves inside the charging bay. You may need to pull them out with pliers.

Code Reader 2.0 Battery Charger



CR2 Battery Charger

The Code Reader 2 (CR2) charger features two charging bays that can accommodate either CR2 units or individual batteries. A power supply and four (4) plastic inserts are included with your charger. The plastic inserts are only used when charging a battery without the CR2 unit. Plug the power cord into the back of the unit and plug the adapter into a wall socket. The unit features two (2) LED's for displaying the charge status. The LED's will remain red until the unit is fully charged. Once charged, the LED's will turn green. The approximate charge time is 4 hours.

Installing and Removing Plastic Inserts for Charging a Battery

The charger comes with four (4) plastic inserts that must be installed if you are charging a battery only.

Follow the steps below to install or remove the inserts:



The battery charger includes four (4) plastic inserts.



To install, you must slide the inserts into the grooves inside the charging bay with the round end towards the front. Push them down hard. You will hear the inserts click into place.



To remove the inserts, grab the round part and slide it out of the grooves inside the charging bay. You may need to pull them out with pliers.

Correctly Inserting Battery and CR2 Unit



To charge an individual battery, make sure the plastic inserts are installed properly in the charging bay and slide the battery in with the battery label facing out.



To charge a CR2 unit, make sure the plastic inserts **ARE NOT** installed in the desired charging bay and slide the unit in with the buttons facing out.



Correctly Inserting Battery and CR2 Unit



To charge an individual battery, make sure the plastic inserts are installed properly in the charging bay and slide the battery in with the battery label facing out.



To charge a CR2 unit, make sure the plastic inserts **ARE NOT** installed in the desired charging bay and slide the unit in with the buttons facing out.

